

CHE261 PROCESS ANALYSIS

APPLICANT

Mollycule

INVENTORS

Shreyas Gupta, Yadav Ankit Shivsurat

CHEMICAL FORMULA

$C_{10}H_{11}N_5O$.


CHEMICAL NAME

Pymetrozine

PROCESS TITLE

Synthesis of Pymetrozine

a) Block Diagram



1. Equipment List & Nomenclature

- T-1: Diethyl Carbonate Storage Tank
- T-2: Hydrazine Hydrate Storage Tank
- T-3: Solvent Storage Tank
- T-4: Carbodihydrazide Storage Tank
- T-5: 3-Formylpyridine Storage Tank
- T-6: Pyridyl Storage Tank
- T-7: Monochloroacetone Storage Tank
- T-8: Pymetrozine Storage Tank
- R-1: Hydrazidation Reactor (Jacketed Agitated)
- R-2: Condensation Reactor (Jacketed Agitated)
- R-3: Cyclization Reactor (Jacketed Agitated)
- C-1: Crystallizer Unit
- H: Heat Exchanger
- W: Washer
- D: Dryer

2. Process Stream List & Nomenclature

- 1: Carbonate Feed
- 2: Hydrazine Feed
- 3: Solvent Stream
- 4: Crude Carbodihydrazide Stream
- 5: Washing Solvent
- 6: waste/byproduct stream
- 7: Wet Carbodihydrazide Stream
- 8: Evaporative Loss Stream
- 9: Dried Carbodihydrazide Stream
- 10: 3-Formylpyridine Feed
- 11: Pyridinyl Hydrazide Mixture
- 12: Purified Pyridinyl Stream
- 13: Dry Pyridinyl Stream
- 14: Monochloroacetone Stream
- 15: Crude Pymetrozine Stream
- 16: Mother Liquor (Crystallization Waste)
- 17: Purified Pymetrozine Crystals
- 18: Washed Pymetrozine Crystals
- 19: Dried Pymetrozine


b) Unit Operations and Process Conditions

1. Raw Material Handling and Feeding


- Storage Tanks (Tanks-1 to Tanks-7)
 - Used for storing reactants, solvents, and catalysts.
- Pumps
 - Transfers raw materials from storage tanks to reactors.
- Flow Control Valves
 - Regulates feed flow into reactors.

2. Reaction Stages

- Reaction 1: Hydrazidation (Carbodihydrazide Synthesis)




- Jacketed & Agitated Reactor-1
 - Reaction Type: Nucleophilic Substitution
 - Temperature: 75–80°C
 - Pressure: Atmospheric
 - Residence Time: 2–4 hours
 - Reactants: Dialkyl Carbonate + Hydrazine Hydrate
 - Solvent: Ethanol/Water
 - Byproducts: Alcohol (methanol or ethanol)
- Reaction 2: Condensation
(Pyridin-3-ylmethylenecarbodihydrazide Synthesis)



- Jacketed & Agitated Reactor-2
 - Reaction Type: Schiff Base Condensation
 - Temperature: 50–70°C
 - Pressure: Atmospheric
 - Residence Time: 3–5 hours
 - Reactants: Carbodihydrazide + 3-Formylpyridine
 - Solvent: Ethanol/THF
 - Byproducts: Water

- Reaction 3: Cyclization (Pymetrozine Synthesis)



- Jacketed & Agitated Reactor-3
 - Reaction Type: Cyclization
 - Temperature: 80–100°C
 - Pressure: Atmospheric or slight vacuum
 - Residence Time: 4–6 hours
 - Reactants: Pyridin-3-ylmethylenecarbodihydrazide + Monochloroacetone + Base ($\text{K}_2\text{CO}_3/\text{Na}_2\text{CO}_3$)
 - Solvent: Ethanol/THF
 - Byproducts: Salt, H_2O , excess reagents

3. Post-Reaction Processing

- Cooling
 - Heat Exchangers (1, 2)
 - Type: Shell & Tube or Plate
 - Cooling Medium: Chilled water or glycol
 - Exit Temperature: ~25–30°C
 - Crystallizer (C-1)
 - Function: Cools down the crude pymetrozine solution to induce crystallization
 - Cooling Medium: Chilled glycol or water jacket
 - Exit Temperature: Adjusted for optimal crystal formation
- Purification & Drying
 - Washers (1, 2, 3)
 - Type: Countercurrent Washing
 - Washing Medium: Water/Ethanol
 - Purpose: Removes impurities, residual reactants, and byproducts
 - Dryers (1, 2, 3)
 - Type: Vacuum Tray Dryer or Rotary Dryer
 - Temperature: 50–70°C
 - Vacuum Level: 50–100 mmHg
 - Purpose: Removes residual moisture from solid product

c) Material Balance

Mass balance:-

1. Preparation of Carbodihydrazide (III)

Materials (Before Reaction)

→ Ethanol = 200g
→ water = 200g } Total solvent
A = 400g


Reactive reagents:-

- Diethyl carbonate (II): 118.1g (1 mol)
- 40% hydrazine hydrate: 275g (40% pure hydrazine)
⇒ (275)(0.4) = 110g
⇒ water from hydrazine = 275 - 110g = 165g.

* Solvent to reagent ratio:-

$$\text{Ratio} = \frac{400}{118.1} = 3.39 \text{ (lies between 3-7)} \\ \text{acc. to R\&D report.}$$

Reaction:



Now, moles of $\text{N}_2\text{H}_4 = \frac{110}{32} \approx \underline{\underline{3.44 \text{ mol}}}$

We assume 0.2 mol hydrazine (free basis) are available to react.

→ According to reaction 2 mol consumed = $2 \times 32 = 64\text{g}$ consumed

→ 0.2 mol $\times 32 = 6.4\text{g}$ remains unreacted

• Reaction products:-

Dihydrazine carbonate $[(\text{NHNH}_2)_2\text{CO}]$: $\approx 90\text{g}$ produced. (1 mol)

Ethanol produced = 92g

solvent & unreacted materials →

Ethanol = 200 + 92 = 292g

water = 200 + 165 = 365g

Excess hydrazine = 6.4g (0.2 mol) + (275 - 64)
 ~~get consumed.~~

c) Material Balance

Around Reactor-1 (mass balance)

②

Before Reaction:-

Component	Mass (g)	Note
Ethanol (solvent)	200g	Added as solvent
Water	200g	Added as solvent
Diethyl carbonate	118.1g	1 mol
40% hydrazine hydrate	275g	110g hydrazine, 165g water
Total	793.1g	

After reaction

Component	Mass (g)	Notes
Dihydrazine carbonate	90g	1 mol product
Ethanol	292g	200 → solvent, 92 → prod. used
Water	365g	200 → Added, 165 → hydr. azine
Unreacted hydr. azine	46g	(110 - 64)
Total	793g	

Washer & dryer:-

20g of water added to filter cake

Total mass after water wash addition = $793.1 + 20$
= 813.1g

After drying product is obtained as 88.9g of carbodihydrazide (III)

weight represents yield of 98.8%.

compared to theoretical product mass of about 90g

Liquid phase (Mother Liquor)

After removing dried solid = $813.1 - 88.9 =$ 724.2g

c) Material Balance

Mass balance :-

(Before workup)

Component	Mass (g)	Notes
Reaction mixture	793.1g	total mass from rxn
wash water	20g	water used to wash filter cake
Total mass	813.1g	

After work-up

Component	Mass (g)	Notes
Solid product (Carbodiimide)	88.9g	98.8% yield (theoretical ~90g)
Liquid phase	724.2g	contains solvents and soluble impurities
Total	813.1g	

Stage-2 : Synthesis of pyridin-3-ylmethylenecarbodiimide (IV)

• Before Reaction

Solvent B: Ethanol = 200g
 water = 100g } Total solvent = 300g

Reactive reagents :-

Carbodiimide (III) = 45g (0.5 mol)

3-formylpyridine = 53.6g (0.5 mol)

Ratio of solvent to carbodiimide :-

$$= \frac{300}{45} = 6.67 \text{ (lies between 5-10 range)} \\ \text{acc. to R\&D report.}$$

Water elimination :-

for 0.5 mol of product, water

$$\text{eliminated} = 0.5 \times 18 = 9g$$

c) Material Balance

Theoretical mass of condensation product: ①

$$\rightarrow \text{total mass of condensing reactants} - \text{eliminated water} \\ = 98.6 - 9 = 89.6 \text{ g}$$

After reaction:

Solid condensation product = 89.6 g (rxn 100% yield completion)

$$\text{water: } 100 \text{ g} + 9.0 \text{ g} = 109 \text{ g}$$

* (Before Reaction)

Component	Mass (g)	Notes
Ethanol	200 g	Added solvent
Water	100 g	Added solvent
Carbodiimide	45 g	0.5 mol (MW \approx 90 g/mol)
3-formylpyridine	53.6 g	0.5 mol (MW = 107.1 g/mol)
Total	398.6 g	

After reaction:

Component	Mass (g)	Notes
Condensation product	89.6 g	98.6 g formed with 9 g of water elimination
Water eliminated (by product)	9 g	produced during condensation
Remaining liquid (mother liquor)	309 g	Contains ethanol & water (100 + 9 + 200)
Total	398.6 g	

* Washer & dryer part:

100 g ethanol is added to dissolve 3-formylpyridine

$$\text{Total mass before washer becomes} = 398.6 + 100 \\ = \cancel{498.6} \underline{498.6 \text{ g}}$$

c) Material Balance

30g of water is added to wash the filter cake
 After drying 89 g of pyridin-3-ylmethylenecarbohydrazide (IV) obtained.

* Before washer & dryer

Component	Mass (g)	Notes
Reaction Mixture	498g	Contains the formed Condensation product, solvent and water (eliminated) in excess
Wash water added	30g	used to wash filter cake
Total	528g	

After washer & dryer:-

Component	Mass (g)	Notes eg
Isolated, solid product	89g	product yield of compound (IV), yield = 99.9%
Mother liquor	439g	Combined solvents and dissolved residues.
Total	528g	

* Stage-3: Preparation of pymetrazine:-


Compound (IV) is used: 71.6 g (0.4 mol)

Monochloroacetone is used: 40.7g (0.44 mol)

Rxn

Compound (IV) + Monochloroacetone \rightarrow pymetrazine + HCl

HCl produced (\approx 0.4 mol, 14.6g) is neutralized by K_2CO_3 .



c) Material Balance

Molecular weight of pymetrozine $\approx 234.05 \text{ g/mol}$

for 0.4 mol $\Rightarrow (0.4)(234.05) \approx 93.6 \text{ g}$

Overall Input:- Compound (IV) = 71.6g

Monochloroacetone = 40.7g

$\text{K}_2\text{CO}_3 = 34.5 \text{ g}$

Solvents (Ethanol + Water) = 350g

Total = 492.6

Solvent C:-

Ethanol = 200g + 50g } dropwise addition
Water = 100g } 350g = Total

Component	Mass (g)	Notes
Comp. (IV)	71.6g	0.4 mol
Monochloroacetone	40.7g	0.44 mol
K_2CO_3	34.5g	0.25 mol
Ethanol	200g	solvent C
Water	100g	solvent C
Ethanol	50g	Used to dissolve monochloroacetone
Total	492.6g	

Mass balance After reaction:

Component	Mass (g)	Note
Pymetrozine (cyclized) product	93.6g	After reaction
KCl	29.8	KCl produced
Water	108.6	from neutralization + initial
Excess K_2CO_3	6.9	$\approx 0.05 \text{ mol}$ remaining
Ethanol	250g	200g initial + 50g dropwise
CO_2	8.8g	0.2 mol CO_2 released
Total	492.7g	

c) Material Balance

Washer and dryer :-

(final solid product obtained = 83.9 g
which is 96.6% of theoretical 86.8 g)

30g of water used to wash filter cake

Before Work-up

Component	Mass	Notes
Reaction Mixt.	492.6	Remains as total mass at after reaction
Wash water added	30g	used to wash filter cake
Total	522.6	

After work-up :-

Component	Mass	Notes
Dried product	83.9g	Final solid product obtained
Mother liquor	438.7g	Contains bulk of solvents, and by products
Total	522.6g	

Now scaling up to produce 1000 kg/day pynchazine,
the inputs required at stage 1 should be.

$$\text{Scale factor} = \frac{1000 \times 10^3}{83.9} = \underline{11,918.}$$

$$\text{Ethanol} = 200 \times 11918 = \underline{2383 \text{ kg}}$$

$$\text{Water} = 200 \times 11918 = \underline{2383 \text{ kg}}$$

$$\text{Diethyl carbonate} = 118.1 \times 11918 = \underline{1407.5 \text{ kg}}$$

$$\text{40\% Hydrazine hydrate} = 275 \times 11918 = \underline{3277.4 \text{ kg}}$$

$$\text{Wash water for filtration} = 20 \times 11918 = \underline{262 \text{ kg}}$$

c) Material Balance

* Scaling for stage 2:-

Scale factor =

89 g of (iv) produced from 45 g $\Rightarrow 89/45 = 1.9778$

Scaled stage 1 feed (9438 kg) yields (88.9 g per 793.1) an output of

$$\left(\frac{88.9}{793.1}\right) \times 9438 \text{ kg} \approx 1056.9 \text{ kg of (iii)}$$

$$(\text{Scale factor})_2 = \frac{1056.9 \times 10^3}{45} = 23486$$

Required

$$\rightarrow \text{Carbonylhydrazide (iii)} = 45 \times 23486 = 1056.9 \text{ kg}$$

$$\rightarrow 3\text{-formylpyridine} = 53 \times 23486 = 1244 \text{ kg}$$

$$\rightarrow \text{Ethanol} = 200 \times 23486 = 4697 \text{ kg}$$

$$\rightarrow \text{Water} = 100 \times 23486 = 2349 \text{ kg}$$

$$\rightarrow \text{Ethanol (in reagent)} = 100 \times 23486 = 2349 \text{ kg}$$

Stage - 3:-

Conversion 71.6 (iv) \rightarrow 83.9 g (factor = 1.171)

Stage (2) produce compound (iv) = 2089 kg

$$\text{Scale factor} = \frac{2089 \times 10^3}{71.6} \approx 29170$$

Required:-

$$\rightarrow \text{Monochloroacetone} = 1186 \text{ kg}$$

$$\rightarrow \text{Potassium Carbonate} = 1007 \text{ kg}$$

$$\rightarrow \text{Solvents (Ethanol)} = 250 \times 29170 = 7293 \text{ kg}$$

$$\rightarrow \text{Solvent (Water)} = 100 \times 29170 = 2917 \text{ kg}$$

d) Reactor Sizing and Cost Estimation

Reactor Capacity Calculation

- The required reactor volumes are calculated using mass balance data and an densities of all the components. The actual reactor design capacity is determined considering only 70% of the total volume can be utilized.

- **Stage 1:**

Input:

Component	Mass (kg/day)
Diethyl Carbonate	1,404.50
Hydrazine Hydrate (40%)	3,279.4 (1,312 kg hydrazine + 1,967.4 kg water)
Ethanol	2,383
Water	2,383
Wash Water	262
Total Mass	9,712.90

d) Reactor Sizing and Cost Estimation

- **Stage 1:**

Volume Estimation:

Component	Mass (kg)	Density (kg/L)	Volume (L)
Diethyl Carbonate	1,404.50	~0.975	1,441.50
Hydrazine Hydrate (40%)	3,279.40	~1.032	3,176.40
Ethanol	2,383	~0.789	3,020.30
Water	2,383	~1.000	2,383.00
Wash Water	262	~1.000	262
Total Volume			10,283.20

Reactor Volume Calculation:

- Total Reactor Volume = (Total Estimated Volume)/0.7
= 10,283.2/0.7
= 14,690.3 L

d) Reactor Sizing and Cost Estimation

Reactor Capacity Calculation

- The required reactor volumes are calculated using mass balance data and an densities of all the components. The actual reactor design capacity is determined considering only 70% of the total volume can be utilized.

- **Stage 2:**

Input:

Component	Mass (kg/day)
Carbohydrazide (III)	1,056.9
3-Formylpyridine	1,244
Ethanol	4,697
Water	2,349
Ethanol (in exaqt)	2,349
Total Mass	11,695.9

d) Reactor Sizing and Cost Estimation

- **Stage 2:**

Volume Estimation:

Component	Mass (kg)	Density (kg/L)	Volume (L)
Ethanol	7,046	~0.789	8,929.7
Water	2,349	~1.000	2,349.0
Carbohydrazide & 3-Formylpyridine	2,300.9	~1.2	1,928.25
Total Volume			13,207.0

Reactor Volume Calculation:

- Total Reactor Volume = (Total Estimated Volume)/0.7
= 13,207/0.7
= 18,867.1 L

d) Reactor Sizing and Cost Estimation

Reactor Capacity Calculation

- The required reactor volumes are calculated using mass balance data and an densities of all the components. The actual reactor design capacity is determined considering only 70% of the total volume can be utilized.

- **Stage 3:**

Input:

Component	Mass (kg)
Monochloroacetone	1,188
Potassium Carbonate	1,007
Ethanol (Solvent)	7,293
Water (Solvent)	2,917
Total Mass	12,405

d) Reactor Sizing and Cost Estimation

- **Stage 3:**

Volume Estimation:

Component	Mass (kg)	Density (kg/L)	Volume (L)
Ethanol	7,293	~0.789	9,243.4
Water	2,917	~1.000	2,917.0
Monochloroacetone & Potassium Carbonate	2,195	~1.2	1,829.2
Total Volume			13,989.6

Reactor Volume Calculation:

- Total Reactor Volume = (Total Estimated Volume)/0.7
= 13,989/0.7
= 19,985.1 L

d) Reactor Sizing and Cost Estimation

Reactor Volume Estimation Table for all 3 reactors:

Reactor	Total Mass in Reactor (kg/day)	Estimated Volume (L)	Design Capacity (L) (Based on 70% usage)
Reactor 1	9,711.9	10,283.2	14,690.3
Reactor 2	11,695.9	13,207 L	18,867
Reactor 3	12,405	13,989.6	19,985.1

d) Reactor Sizing and Cost Estimation

Capital Cost Estimation

- The cost estimation is based on the Matche Equipment Cost Calculator and we are utilizing Jacketed and Agitated Reactor in each with material as Glass Lined CS and pressure set between atmospheric to 25 psi.

Capital Cost Table:

Equipment	Design Capacity (gallons)	No. of Units	Cost/unit (\$)
Reactor 1 (Jacketed, Agitated, Glass- lined CS)	3880.7	1	96,300
Reactor 2 (Jacketed, Agitated, Glass- lined CS)	4984.13	1	110,000
Reactor 3 (Jacketed, Agitated, Glass- lined CS)	5279.5	1	113,400

Total Cost: \$ 319,700 = ₹ 2,73.53,116

References:

- <https://patents.google.com/patent/CN104844574A/en>
- <https://www.matche.com/equipcost/Reactor.html>

Contribution of each member



Shreyas Gupta (230991)

- Designed the Process Flow Diagram (PFD), incorporating all unit operations such as reactors, washers, dryers, crystallizers, and heat exchangers.
- Defined key process conditions (temperature, pressure, solvent recovery, waste handling) for efficient operation.
- Sized the reactors based on process conditions, ensuring 70% of total volume utilization for reaction mixtures.
- Conducted a capital cost estimation, doing cost analysis of Glass-Lined Carbon Steel (GLCS) reactors.

Ankit Yadav(231181)

- Performed a detailed material balance for the scaled-up process plant (1000 kg/day).
- Determined input and output flow rates for all process streams and unit operations.
- Established assumptions for simplified yet accurate calculations, ensuring precise mass flow tracking.
- Optimized reactant consumption and efficiency, reducing material losses and improving yield.

Sign the pdf and upload

NAME	ROLL NO	SIGNATURE
HARSHITJAISWAL	230460	
SHREYAS GUPTA	230991	
YADAV ANKIT SHIVSURAT	231181	